

スマートフォン用製品適合リスト[4極端子] (ヘッドホン)

2018年1月24日

現在の検証結果となります。なお、本適合リストは、スマートフォン購入時にプリインストールされている基本アプリケーション※での検証結果に基づく内容です。

それ以外のアプリケーションでは動作保証いたしかねます。

※予めユーザー登録が必要なアプリケーションなどでは動作しない場合があります。

○: 適合

- : 不適合

△: 一部動作制限あり。コントロールボタンは着信応答/終話の操作に対応しています。音楽・動画再生/一時停止の操作はできません。

※1 動画再生時での再生/一時停止の操作はできません。

※2 動画撮影時の收音にも対応しています。

※3 ヘッドホンに付属の変換コードを接続することで使用できます。

※4 スマートフォンに付属の純正の変換コードを使うことで使用できます。

*ATH-WS99BT/ATH-S700BTにつきましては、付属のスマートフォン用コントローラー付きコードを使用した場合の検証結果となります。

スマートフォン(iOS)								
スマートフォン機種名	ヘッドホン							メーカー
	■ATH-CK330iS ■ATH-CKL220iS ■ATH-CHX5iS ■ATH-CHX7iS ■ATH-CKX5iS ■ATH-CKX7iS ■ATH-CKX9iS	■ATH-WS99BT* ■ATH-PDG1 ■ATH-PG1 ■ATH-SPORT1iS ■ATH-CKL203iS ■ATH-S700BT* ■ATH-CKF77iS ■ATH-J100iS	■ATH-SR9 ■ATH-MSR7 ■ATH-CKR3iS ■ATH-CKR30iS ■ATH-CKS550iS ■ATH-CKS1000 ■ATH-CKS55XiS ■ATH-WS99	■ATH-PRO5MK3 ■ATH-OX7AMP ■ATH-OX5 ■ATH-RE700	■ATH-ANC9	■ATH-CK323iS ■ATH-C505iS ■ATH-S100iS	■ATH-AR5	
iPhone X	○※4	○※4	○※4	○※4	○※4	○※4	○※4	アップル
iPhone 8	○※4	○※4	○※4	○※4	○※4	○※4	○※4	アップル
iPhone 8 Plus	○※4	○※4	○※4	○※4	○※4	○※4	○※4	アップル
iPhone 7	○※4	○※4	○※4	○※4	○※4	○※4	○※4	アップル
iPhone 7 Plus	○※4	○※4	○※4	○※4	○※4	○※4	○※4	アップル
iPhone SE	○	○	○	○	○	○	○	アップル
iPhone 6s	○	○	○	○	○	○	○	アップル
iPhone 6s Plus	○	○	○	○	○	○	○	アップル
iPhone 6	○	○	○	○	○	○	○	アップル
iPhone 6 Plus	○	○	○	○	○	○	○	アップル
iPhone 5s	○	○	○	○	○	○	○	アップル
iPhone 5c	○	○	○	○	○	○	○	アップル
iPhone 5	○	○	○	○	○	○	○	アップル
iPhone 4S	○	○	○	○	○	○	○	アップル
iPhone 4	○	○	○	○	○	○	○	アップル
iPhone 3GS	○	○	○	○	○	○	○	アップル
iPhone 3G	○	○	○	○	○	○	○	アップル

スマートフォン(Android/その他)									
携帯電話会社 (キャリア)	スマートフォン機種名	ヘッドホン							メーカー
		■ATH-CK330iS ■ATH-CKL220iS ■ATH-CHX5iS ■ATH-CHX7iS ■ATH-CKX5iS ■ATH-CKX7iS ■ATH-CKX9iS	■ATH-WS99BT* ■ATH-PDG1 ■ATH-PG1 ■ATH-SPORT1iS ■ATH-CKL203iS ■ATH-S700BT* ■ATH-CKF77iS ■ATH-J100iS	■ATH-SR9 ■ATH-MSR7 ■ATH-CKR3iS ■ATH-CKR30iS ■ATH-CKS550iS ■ATH-CKS1000 ■ATH-CKS55XiS ■ATH-WS99	■ATH-PRO5MK3 ■ATH-OX7AMP ■ATH-OX5 ■ATH-RE700	■ATH-ANC9	■ATH-CK323iS ■ATH-C505iS ■ATH-S100iS	■ATH-AR5	
docomo	SO-02K(Xperia XZ1 Compact)	○	○	○	○	○	○	ソニー	
docomo	SO-01K(Xperia XZ1)	○	○	○	○	○	○	ソニー	
docomo	SO-04J(Xperia XZ Premium)	○	○	○	○	○	○	ソニー	
docomo	SO-03J(Xperia XZs)	○	○	○	○	○	○	ソニー	
docomo	SO-02J(Xperia X Compact)	○	○	○	○	○	○	ソニー	
docomo	SO-01J(Xperia XZ)	○	○	○	○	○	○	ソニー	
docomo	SO-04H(Xperia X Performance)	○	○	○	○	○	○	ソニー	
docomo	SO-03H(Xperia Z5 Premium)	○	○	○	○	○	○	ソニー	
docomo	SO-02H(Xperia Z5 Compact)	○	○	○	○	○	○	ソニー	
docomo	SO-01H(Xperia Z5)	○	○	○	○	○	○	ソニー	
docomo	SO-04G(Xperia A4)	○	○	○	○	○	○	ソニー	
docomo	SO-03G(Xperia Z4)	○	○	○	○	○	○	ソニー	
docomo	SO-02G(Xperia Z3 Compact)	○	○	○	○	○	○	ソニー	
docomo	SO-01G(Xperia Z3)	○	○	○	○	○	○	ソニー	

