



携帯電話会社 (キャリア)	スマートフォン機種名	ヘッドホン									メーカー
		■ATH-CK330iS ■ATH-CK350iS ■ATH-CK350XiS ■ATH-CKL220iS ■ATH-CHX5iS ■ATH-CHX7iS ■ATH-CKX5iS ■ATH-CKX7iS ■ATH-CKX9iS	■ATH-WS99BT* ■ATH-PDG1 ■ATH-PG1 ■ATH-SPORT1iS ■ATH-CKL203iS ■ATH-S700BT* ■ATH-CKF77iS ■ATH-J100iS	■ATH-SR9 ■ATH-MSR7 ■ATH-CKR3iS ■ATH-CKR30iS ■ATH-CKS550iS ■ATH-CKS550XiS ■ATH-CKS1000 ■ATH-WS99	■ATH-CKS55XiS	■ATH-PRO5MK3 ■ATH-OX7AMP ■ATH-OX5 ■ATH-RE700	■ATH-ANC9	■ATH-CK323iS ■ATH-C505iS ■ATH-S100iS	■ATH-AR5 ■ATH-M50xBT	■ATH-C200iS	
docomo	SC-02L(Galaxy Feel2)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-01L(Galaxy Note9)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-02K(Galaxy S9)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-03K(Galaxy S9+)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-01K(Galaxy Note8)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-04J(Galaxy Feel)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-02J(Galaxy S8)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SC-03J(Galaxy S8+)	○	○	○	○	○	○	○	○	○	Samsung電子
docomo	SH-03K(AQUOS R2)	○	○	○	○	○	○	○	○	○	シャープ
docomo	SH-01K(AQUOS sense)	○	○	○	○	○	○	○	○	○	シャープ
docomo	SH-03J(AQUOS R)	○	○	○	○	○	○	○	○	○	シャープ
docomo	DM-01J(Disney Mobile on docomo)	○	○	○	○	○	○	○	○	○	シャープ
docomo	SH-02J(AQUOS EVER)	○	○	○	○	○	○	○	○	○	シャープ
docomo	SH-04H(AQUOS ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-02H(AQUOS Compact)	○	○	○	○	○	○	○			シャープ
docomo	SH-01H(AQUOS ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-01G(AQUOS ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-04G(AQUOS EVER)	○	○	○	○	○	○	○			シャープ
docomo	SH-03G(AQUOS ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-02G	○	○	○	○	○	○	○			シャープ
docomo	SH-05F	○	○	○	○	○	○	○			シャープ
docomo	SH-04F(AQUOS ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-03F(スマートフォン for ジュニア2)	○	○	○	○	○	○	○			シャープ
docomo	SH-02F(AQUOS PHONE EX)	○	○	○	○	○	○	○			シャープ
docomo	SH-01F(AQUOS PHONE ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-07E(AQUOS PHONE si)	○	○	○	○	○	○	○			シャープ
docomo	SH-06E(AQUOS PHONE ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-05E(スマートフォン for ジュニア)	○	○	○	○	○	○	○			シャープ
docomo	SH-04E(AQUOS PHONE EX)	○	○	○	○	○	○	○			シャープ
docomo	SH-02E(AQUOS PHONE ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-01E(AQUOS PHONE si)	○	○	○	○	○	○	○			シャープ
docomo	SH-09D(AQUOS PHONE ZETA)	○	○	○	○	○	○	○			シャープ
docomo	SH-07D(AQUOS PHONE st)	○	○	○	○	○	○	○			シャープ
docomo	SH-04D(Q-pot.Phone)	○	○	○	○	○	○	○			シャープ
docomo	SH-01D(AQUOS PHONE)	○	○	○	○	○	○	○			シャープ
docomo	SH-13C(AQUOS PHONE f)	○	○	○	○	○	○	○			シャープ
docomo	SH-12C(AQUOS PHONE)	○	○	○	○	○	○	○			シャープ
docomo	SH-03C(LYNX 3D)	△	△	△	△	△	△	△			シャープ
docomo	F-04K(arrows Be)	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	富士通
docomo	F-03K(らくらくスマートフォン me)	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	富士通
docomo	F-01K(arrows NX)	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	富士通
docomo	F-05J(arrows Be)	○	○	○	○	○	○	○	○	○	富士通
docomo	F-04J(らくらくスマートフォン 4)	○	○	○	○	○	○	○	○	○	富士通
docomo	L-03K(LG style)	○	○	○	○	○	○	○	○	○	LG Electronics Japan
docomo	DM-01K(Disney Mobile on docomo)	○	○	○	○	○	○	○	○	○	LG Electronics Japan
docomo	L-01K(V30+)	○	○	○	○	○	○	○	○	○	LG Electronics Japan
docomo	L-01J(V20 PRO)	○	○	○	○	○	○	○	○	○	LG Electronics Japan
docomo	Z-01K(M)	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	○※1	ZTE
docomo	MO-01J(MONO)	○	○	○	○	○	○	○	○	○	ZTE
docomo	Pixel 3	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	Google
docomo	Pixel 3 XL	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	○※1※4	Google
docomo	HW-01K(HUAWEI P20 Pro)	○※4	○※4	○※4	○※4	○※4	○※4	○※4	○※4	○※4	Huawei
docomo	HW-03E(Ascend D2)	○	○	○	○	○	○	○			Huawei

